

Quale controller per quale forno?



	N 100 - N 2200/14	NW 150 - NW 1000/H	N 100 DB50 - N 1500/14 DB..	W 1000 - W 7500/14	W ../.. DB..	H ../LB, H ../LT	H ../DB..	HT 08/16 - HT 450/18	HTC 16/16 - HTC 450/16	HFL 16/16 - HFL 160/17	HT ../.. DB..	HT ../.. LB, HT ../.. LT	HT ../.. LB DB.., HT ../.. LT DB..	NA 120/65 DB200 - NA 1500/60B DB200	LH 15/12 - LH 216/14, LF 15/13 - LF 120/14	L 9/11 BO - L 40/11 BO	LHT 08/17 BO	N 300 BO - NB 650 BO	HF ..	DF 23/244/5/10 WK - DF 64/320/5/10 WK	NB ..	WB ..	N 100/WAX - N 440/WAX	WHTC ..
Pagina del catalogo	16	18	20	22	24	28	30	34	36	37	38	40	44	48	52	56	57	58	62	64	70	71	72	73
Controller																								
B500	●	●													●								●	
C540	○	○													○								○	
C550																●								
P570	○	○	● ¹	●		● ¹		● ¹	● ¹	● ¹	● ¹	● ¹			○		●							●
H500/PLC	○			○				● ¹	● ¹	● ¹	● ¹	● ¹			○									○
H1700/PLC			● ¹	○	●	● ¹	●	○	○	○	○	○	○	○	○			●	●		●	●	○	○
H3700/PLC			○	○	○	○	○	○	○	○	○	○	○	○	○						○	○	○	○
NCC			○	○	○	○	○	○	○	○	○	○	○	○					○	●	○	○		○

● Standard

○ Opzione

¹A seconda del modello