

Product Advantages Fusing Furnaces



Closely arranged roof heating elements protected in quartz glass tubes for direct, even heating of the glass



Level table surface with rugged refractory insulation and marked charge surface



Exclusive use of insulation materials without categorization according to EC Regulation No 1272/2008 (CLP). This explicitly means that aluminosilicate wool, also known as "refractory ceramic fiber" (RCF), which is classified and possibly carcinogenic, is not used.



Appealing, dual-shell stainless steel housing



Large handles on the right and left sides of the lid



Gas pressure springs for easy opening and closing of the lid



Adjustable, large quick-release fasteners – also suitable when working with gloves



Closable opening for ventilation, for faster cooling and to observe the charge



Rugged base on castors with surface for glass and tools



Ergonomic charging height of 860 mm



Solid state relays ensure low-noise heater operation



Heating switches off when the lid is opened