

Product Advantages Top Loaders



Three-layer insulation with high-quality, energy-saving backing insulation for low external temperatures and a good energy balance for kilns up to 60 liters



DEKRA certification



Two-layer insulation with durable light-weight refractory bricks and energy-saving backing insulation adapted to the maximum kiln temperature for kilns from 80 liters



Housing shell made from structured stainless steel



Exclusive use of insulation materials without categorization according to EC Regulation No 1272/2008 (CLP). This explicitly means that alumino silicate wool, also known as "refractory ceramic fiber" (RCF), which is classified and possibly carcinogenic, is not used.



Durable lid seal (brick on brick)



Adjustable lid with quick-release lock and padlock



Solid state relays ensure low noise heater operation



Integrated gas-pressured springs for easy opening and closing of the lid



Easy to use controller for precise temperature control, removable for comfortable operation



Important data about power consumption and operating hours available via the information menu of the controller



Thermocouple protected in the insulation



Infinitely adjustable air inlet in opening in the kiln bottom for good ventilation and short cooling times



Bypass connection for an exhaust air pipe (80 mm diameter)