

Material-ID	100005
Hersteller	GC
Beschreibung	Reserve
Material Name	Initial LiSi Press

		Prozesse														
		Starten					Halten					Pressen				
Programmnummer	Name	Freigeschaltet	Rate [°/min]	Temperatur [°]	Haltezeit [s]	Vakuum	Freigeschaltet	Rate [°/min]	Temperatur [°]	Haltezeit [s]	Vakuum	Freigeschaltet	Rate [°/min]	Temperatur [°]	Haltezeit [s]	Vakuum
		1	HT-MT-LT 100g	x		700			x	60	898	1500	x	x		898
2	HT-MT-LT 200g	x		700			x	60	910	1500	x	x		910	300	x
3	MO 100g	x		700			x	60	903	1500	x	x		903	300	x
4	MO 200g	x		700			x	60	913	1500	x	x		913	300	x

Material-ID	100005
Manufacturer	GC
Description	Reserve
Material name	Initial LiSi Press

		Processes														
		Starting					Holding					Pressing				
Program number	Name	Enable	Rate [°/min]	Temperature [°]	Hold time [s]	Vacuum	Enable	Rate [°/min]	Temperature [°]	Hold time [s]	Vacuum	Enable	Rate [°/min]	Temperature [°]	Hold time [s]	Vacuum
		1	HT-MT-LT 100g	x		700			x	60	898	1500	x	x		898
2	HT-MT-LT 200g	x		700			x	60	910	1500	x	x		910	300	x
3	MO 100g	x		700			x	60	903	1500	x	x		903	300	x
4	MO 200g	x		700			x	60	913	1500	x	x		913	300	x